



**Double Passage
Full Height
Rotor Turnstile**

RTD-20

ASSEMBLY AND OPERATION MANUAL



CE EAC



Double Passage Full Height Rotor Turnstile

RTD-20

Assembly and Operation Manual

CONTENT

1	APPLICATION.....	3
2	OPERATION CONDITIONS.....	3
3	TECHNICAL SPECIFICATIONS	4
4	DELIVERY SET.....	5
4.1	Standard delivery set.....	5
4.2	Optional equipment and installation tools.....	6
5	DESIGN AND OPERATION.....	9
5.1	Main features.....	9
5.2	Design of the turnstile.....	10
5.3	Control of the turnstile	14
5.3.1	The RC-panel.....	14
5.3.2	Control modes.....	15
5.3.3	Logic operational sequence in the pulse operation mode	16
5.3.4	Parameters of control signals.....	16
5.3.5	Operation from the RC-panel	18
5.3.6	<i>Fire Alarm</i> device	19
5.3.7	Operation via an ACS-controller.....	19
5.4	Optional devices that can be connected to the turnstile	19
5.4.1	Signal parameters of relay outputs.....	20
5.4.2	Intrusion detector and siren.....	20
5.4.3	Remote light indicators.....	21
5.5	Operational contingencies and feedback.....	21
6	MARKING AND PACKAGING.....	23
7	SAFETY REQUIREMENTS.....	24
7.1	Installation safety requirements.....	24
7.2	Operational safety requirements.....	24
8	INSTALLATION.....	25
8.1	General recommendations	25
8.2	Tools and equipment required for assembly.....	25
8.3	Allowable cable lengths	26
8.4	Installation of the turnstile.....	26
8.5	Selection of the passage mode	34
8.6	Adjustment of damper device RTD-20.2.....	35
8.6.1	The damper device operation check	36
8.6.2	The damper device adjustment order.....	36
8.7	Replacement of walkway downlights	37
8.8	The turnstile performance check	38
8.8.1	Verification of the mechanical and emergency unblocking of the turnstile	38
8.8.2	Verification of the turnstile performance in test mode.....	38
8.9	Turnstile and optional equipment connection layout.....	41
9	OPERATING THE TURNSTILE	43
9.1	Starting procedure.....	43
9.2	Pulse control mode.....	43
9.3	Potential control mode.....	46
9.4	Emergency actions.....	46
9.5	Troubleshooting.....	47
10	MAINTENANCE	47
11	TRANSPORTATION AND STORAGE	49
	APPENDIX 1. Algorithm of control signals generation in pulse control mode	51
	APPENDIX 2. Algorithm of control signals generation in potential control mode	52
	APPENDIX 3. The markup schemes for joint installation of checkpoint components and RTD-20	53

Dear customers!

*Thank you for purchasing the PERCo product.
Please follow instructions given in this Manual carefully, and this quality product
will provide many years of trouble-free use.*

The Assembly and Operation Manual (hereinafter – the Manual) contains the instructions you will need for safe transportation, storage, installation, operation and maintenance of the **RTD-20 double passage full height rotor turnstile**.

Abbreviations adopted in the Manual:

- ID – intrusion detector;
- PS – power supply;
- OD – operating device (one of the two functional parts of the turnstile);
- WD – walkway downlights;
- RC-panel – remote control panel;
- WRC – wireless remote control;
- ACS – access control system.

1 APPLICATION

The **RTD-20 double passage full height rotor turnstile** (hereinafter – the *turnstile*) is a doubled modification of the **RTD-16** full height rotor turnstile. The turnstile is used as two independently controlled blocking devices (hereinafter – the OD), designed for management of pedestrian flows and access control at entrance points of facilities and areas with high security requirements and necessity for full closure of the passageway.

Available versions of the turnstile:

- **RTD-20.1** – model with motorized drives;
- **RTD-20.2** – model with mechanical drives.

RTD-20.1S and **RTD-20.2S** are equipped with rotors made of stainless steel.

It is advisable to determine the number of turnstiles necessary for providing fast and convenient pedestrian passage on the basis of the corresponding throughput (see Sect. 3).

2 OPERATION CONDITIONS

The turnstile with regard to resistance to environmental exposure complies with GOST 15150-69, category N2 (outdoor operation).

Operation of the turnstile is allowed at ambient temperature from – 40°C to +50°C (under shelter – to +55°C) and at relative air humidity of up to 98% at +25°C.

The RC-panel with regard to resistance to environmental exposure complies with GOST 15150-69, category NF4 (operation in premises with climate control).

Operation of the RC-panel is allowed at ambient air temperature from +1°C to +40°C and at relative humidity of up to 80% at +25°C.

3 TECHNICAL SPECIFICATIONS¹

The turnstile meets the requirements applicable to this type of equipment in accordance with GOST R 51241-2008.

DC voltage:

Turnstile	24±2.4 V
Walkway downlights	12±1.2 V

Power consumption²:

RTD-20.1 turnstile excluding walkway downlights

for OD №1	max. 105 ³ W
for OD №2	max. 105 ³ W

RTD-20.2 turnstile excluding walkway downlights

for OD №1	max. 30 W
for OD №2	max. 30 W

Walkway downlights (total for both passages)..... 20 W

Throughput of every OD:

in the single passage mode	20 persons/min
in the free passage mode	30 persons/min

Average throughput of every OD

in the single passage mode

2000 persons/day

Width of every passageway

630 mm

Rotation force in the center of the barrier wing

max 3 kgf

Ingress Protection Rating of the top channel

IP54 (EN 60529)

Electric Shock Protection Class

III (IEC 61140)

Mean time to failure of every OD

min 2,000,000 passages

Mean lifetime

min 8 years

Dimensions (length × width × height)

2480×1595×2303 ⁴ mm

Net weight:

RTD-20.1 turnstile	max 370 kg
RTD-20.2 turnstile	max 375 kg

¹ Given characteristics are applicable to all turnstile models if the exact model is not indicated.

² ODs are electrically isolated and require separate power supplies.

³ Maximal at the motor drive overload.

⁴ Overall dimensions are shown in Fig. 1.

4 DELIVERY SET

4.1 Standard delivery set

Box №1 «Top Channel» 1, includes:

Primary parts:

Assembled top channel with cover	1
Key for mechanical release lock	8

Installation tools:

Plug Ø10, dark blue color	14
Screw M5×16 (top channel cover fastening)	6
Spring washer 5	6
Fixed brace rod 100 mm	50

Spare parts:

Self-adhesive cable tie mount	2
Plug Ø10, dark blue color	2
Cable bushing Ø16	6
Hex-nut wrench for adjustment of the damper ¹	2

Technical documentation:

Assembly and operation manual	1
Certificate	1

Box №2 «Rotor 1», Box №3 «Rotor 2» 2, each box contains:

Primary parts:

Shaft rotor section with fittings	1
Rotor section	2
Half-coupling	2

Installation tools:

Bolt M8×30 (half-coupling)	4
Spring washer 8 (half-coupling)	4
Bolt M8×12	20
Bolt M8×14	4
Spring washer 8	24
Plug Ø16	36

Box №4 «Left Section of Guide Barrier Set» 2, each box contains:

Primary parts:

Left section of guide barrier set in assembly with LED directional indicator and cable	1
Supporting girder	1

Box №5 «Right Section of Guide Barrier Set»..... 2, each box contains:

Primary parts:

¹ Only for the model *RTD-20.2*

Right section of guide barrier set in assembly with LED directional indicator and cable	1
--	---

Box №6 «Divider» 1, includes:

Primary parts:

Divider section	2
Divider top girder	1
Lower support of rotors	1
Supporting flange of bottom rotation unit	2
Fluorine insert of bottom rotation unit	2
Slip washer of bottom rotation unit	2
RC-panel with cable 7 m ¹ long	2
Cable duct for cabling from the bottom	1

Installation tools:

Bolt M5×12	8
Bolt M8×16	8
Bolt M8×25	6
Nut M10	4
Washer 8	6
Washer 10	4
Spring washer 8	14
Spring washer 10	4
Plate	6
Plug Ø16	8
Template for markup on the mounting surface (HDF)	1

Spare parts:

Plug Ø16	4
Plug Ø38	6
Plug 60×30	2
Powder paint RAL5010	1
Powder paint RAL7035	1
Channel beam for cables	2

4.2 Optional equipment and installation tools

Optional equipment and supplementary installation tools can be supplied on request additionally to the standard delivery set. Technical data of optional equipment is given in operating documentation supplied with the equipment.

Optional equipment:

Protective canopy RTC-20	1
Sections and railings MB-16	in sufficient qty
Full height security gate WHD-16	1
Turnstile power supply unit 24V / 5.5A	2
Walkway downlights power supply unit 12V / 2A	1

¹ Remote control panel with 40 m cable is supplied on request.

Wireless remote control kit ¹ 2

Supplementary installation tools:

Foundation frame *PERCo-RF-20* 1
Anchor PFG IR 10-15 with bolt M10×60 (“SORMAT”, Finland) 24
Anchor PFG IR 16-25 with bolt M16×100 (“SORMAT”, Finland) 2
Anchor PFG IR 10-15 with bolt M10×60 for cable duct 2

¹ Wireless remote control kit includes the receiver connectable to the CU and tag transmitters with 40 m coverage.




Figure 1. Overall dimensions

5 DESIGN AND OPERATION

5.1 Main features

- The turnstile consists of two independent OD's, each of which is a full height rotor turnstile. **RTD-20** allows to save at least 25% of space compared to the use of two **RTD-16** turnstiles.
- Every OD of the turnstile can be operated in two operating modes – as a standalone unit operated from either RC-panel or wireless remote control, or as part of various identification and access control systems operated automatically via external ACS-controller.
- Each of the two ODs of the turnstile is a normally closed unit. When the power supply is off the rotor barrier wings are locked in closed position.
- Combined coating of all turnstile elements with zinc and powder paint ensures high corrosion resistance and long years of service in harsh environments; the turnstile versions bearing “S”-marking in the index have the rotors with sections made of stainless steel.
- High durability of polymeric powder coating keeps the elegant appearance intact in intensive use conditions.
- For a more comfortable passage **RTD-20.1** model includes an electric gear motor providing an automatic rotation of the rotor. **RTD-20.2** model includes mechanic reset drive that allows automatic rotation of the rotor until the rotor is in the home position.
- Additional installation of an intrusion detector or a siren provides a possibility for sound alarm on unauthorized attempts of passage.
- The turnstile has built-in LED directional indicators for each passage direction for each OD of the turnstile, there is a possibility of optional installation of remote light indicators.
- Use of lock-chamber – special space in the construction of the turnstile – allows providing the site with intense access control in each OD of the turnstile.
- The turnstile is fit for installation on soft ground by means of a specially designed foundation frame **RF-20**.
- For protection from environmental exposure and providing an extra barrier against climbing over the turnstile design enables installation of **RTC-20** protective canopy that can be optionally included in the delivery set.
- The turnstile design enables assembly together with **WHD-16** full height gate that can be optionally included in the delivery set and can be used for providing an emergency or escape passage with a remote control and for carrying bulky cargo through the control area.
- For optimal organization and restriction of control areas the turnstile design enables assembly together with sections of **MB-16** full height railings that can be optionally included in the delivery set. In case of necessity **MB-16** railings can be equipped with barrier plates for an extra barrier against climbing over and supporting girders for reinforcing the construction.
- The turnstile design offers lightning of every passageway with pair of LEDs.
- The turnstile design provides the possibility of power cable grooming and control from external devices – through the top channel. It is possible to mount an additional cable duct (included in the standard delivery set) for cable grooming from below through mounting surface. The channel is made in the same design as the turnstile.

- It is possible to install up to three turnstiles in line with upper transit cabling; at this it is still possible to use standard **RTC-20** protective canopy.
- There are two built-in mechanical release locks to unlock the turnstile when necessary (two locks per each OD of the turnstile) for free passage in either direction by means of a key.
- Installation of an emergency unlocking device sending the *Fire Alarm* unlocking signal (e.g. the fire alarm control panel) enables to unlock each OD of the turnstile remotely for free passage in either direction in emergency situations.
- The turnstile is powered with a safe operation voltage – 12 and 24 V DC.
- Reduced power consumption of the turnstile results in lower operating costs.

5.2 Design of the turnstile




Figure 2. Design of the turnstile:

- 1 – rotors; 2 – rotor section¹; 3 – bottom bearing rotation units; 4 – couplings²;
 5 – divider sections; 6 – section of guide barrier set (left and right);
 7 – supporting girders; 8 – divider top girder; 9 – top channel;
 10 – top channel cover; 11 – lower support of rotors; 12 – cable entry holes;
 13 – LED indicators³; 14 – indication cables;

¹ Rotor assembly scheme is shown in Fig. 19.

² Coupling shown in Fig. 18.

³ Supplied complete with sections of guide barrier.

15 – power cables for turnstile ODs №1 and №2¹; 16 – RC-panel №1 and №2 with cables;
17 – *Fire Alarm* cable⁴; 18 – walkway downlights power cables⁴

Design of the turnstile is shown in Fig. 2. The numbers of the positions in the Manual are given according to Fig. 2.

The turnstile consists of two independent ODs, each of which is a full-fledged full height turnstile. Each OD consists of:

- rotor (1) consisting of three sections (2);
- guide barrier consisting of left and right sections (6) and supporting girder (7);
- two LED directional indicators (13);
- RC-panel (16) with cables;
- units inside the top channel enabling operation of the turnstile.

Common to both OD's are:

- lower support of rotors (11);
- divider of the turnstile, consists from two sections (5) and top girder (8);
- top channel (9) with cover (10).

The **rotor** (1) is an assembly of three separate sections (2). Each section serves as a barrier wing and consists of vertical support with 10 welded barrier arms. Bottom part of the both rotors is inserted into the bottom bearing rotation units (3), that are mounted in the lower support (11), upper part through the union joint is attached to the shaft of operating mechanism. The lower support is grappled by anchor bolts to the mounting surface.

The **guide barrier set** consists of two sections (6): left and right. Each section consists of a supporting girder (7) with flanges. The outer supporting girders are furnished with built-in LED directional indicators (13) with indication cables (14) running through and out of the posts. Each flange has two mounting holes for fixing the guide barrier sections to the mounting surface. Together with divider section the guide barrier sections form the turnstile passageway. The outer supporting girders can be mounted with ACS readers or other supplementary equipment if necessary.

The **supporting girder** (7) joins the guide barrier sections and provides stability and support for the top channel (9). Indication cables and, if necessary, cables from ACS readers and other equipment are mounted inside the supporting girder.

The **turnstile divider** consists of the two sections (5) that are connected to each other by the top girder (8) from the top side. Each section consists of two vertical posts, connected by profiled horizontal railing. The top girder of the divider acts as a center support of the top channel (9). Divider section posts are connected by the anchor bolts to the mounting surface through the holes in the bottom collars.

The **top channel** (9) joins turnstile elements into a single structure, and serves for placement of basic units ensuring the turnstile operation: operating mechanisms and the control units of the both OD. Four mechanical release locks are mounted underneath the top channel (two locks for each OD). The access to locks is possible from below from the passage side. Each lock is designed for unlocking the rotor (1) in the direction of the lock's side. The top channel is protected by the cover (10) fixed with six screws from below. After fixing the screw holes are closed with plastic plugs.

Each OD has independent operating mechanism and control unit.

¹ Not included in the standard delivery set.

The **operating mechanism** of each OD is installed on a separate base. The shaft of the operating mechanism is connected to the rotor (1) shaft with the union joint (4) consisting of two half-couplings.

The operating mechanisms of the **RTD-20.1** model includes also an electric gear motor (Fig. 3). In the single passage mode, at the beginning of the passage through the turnstile, the motor switches on as soon as the rotor is revolved about $>12^\circ$, and makes further automatic rotation in the direction of passage until the rotor is in the home position where it is securely locked. In the free passage mode, the electric motor switches into operation only to slow down the rotation of barrier wings near the home position.

The operating mechanisms of the **RTD-20.2** includes a mechanical gear motor (Fig. 4). As soon as the rotor has been revolved about $>60^\circ$ the operating mechanism due to the springs energy continues rotation until the rotor is in the home position where it is securely locked. As soon as the rotor has been revolved about $>60^\circ$ the operating mechanism in both modifications blocks the reverse rotation.




Figure 3. Top channel with cover off RTD-20.1 model




Figure 4. Top channel with cover off RTD-20.2 model

The **control unit** (Fig. 3 and 4) of each OD is designed as a separate device in a plastic case and performs control over the turnstile in accordance with the algorithm and received control commands.

The CU microcontroller processes incoming commands (contacts *Unlock A*, *Stop*, *Unlock B* and *Fire Alarm*), keeps track of the signals from the optical rotation sensors, optical sensors of the locking devices and from an intrusion detector (*Detector* contact). Basing on these signals the microcontroller generates commands to the turnstile operating mechanism and signals to the external devices: for control over indication on the RC-panel (*RC Led A*, *RC Led Stop* and *RC Led B*), signal of the rotor rotation in the respective direction (*PASS A* and *PASS B*), operation contingency signal (*Ready*), alarm signal (*Alarm*); and relays the current status of the intrusion detector (*Det Out*).

For connection convenience all the CU connectors are positioned on a DIN-rail (see Fig. 3 and 4, Table 1) mounted inside the top channel. There are two possibilities of cables wiring to the DIN-rail:

- through the upper hole for cables mounting (12) on the sides of the top channel.
- through the lower hole in in the mounting surface and then up the Cable duct (from the delivery set) into the top channel.

The cable bushings from the delivery set are used for cables wiring through the upper holes. Spare holes are covered with plastic plugs.

The cable duct for the bottom grooming gets screwed to the mounting surface by two anchor bolts through the holes in the collar. The top side of the cable channel secures to the end surface of the top channel.

It is possible to have a transit cabling through the top channel at installation of several turnstiles (up to 3 turnstiles) in line.

Table 1. DIN-rail contacts

No DIN	Contact	Operation
1	+24V	Connection of the external power source.
2	GND	
3	+12V	Connection of the intrusion detector +12V
4	DETECTOR	Input of the intrusion detector
5	GND	Common
6	FIRE ALARM	Input control of emergency passage unblocking. Wire jumper is factory-installed
7	GND	
8	RC SOUND	Control output of the sound indication of the RC-panel
9	UNLOCK A	Control input by unlocking direction A
10	STOP	Control input by passage block
11	UNLOCK B	Control input by unlocking direction B
12	RC LED A	Output indication of unlocking direction A on the RC-panel
13	RC STOP	Output indication of passage blocking on the RC-panel
14	RC LED B	Output indication of unlocking direction B on the RC-panel
15	IMP/POT	To install the wire jumper "IMP/POT". At supply the wire jumper is off that corresponds to the pulse control mode.
16	GND	
17	+12V	Output +12V for power supply of optional devices
18	ALARM 1	Outputs for the siren connection
19	ALARM 2	
20	COMMON	Common for outputs <i>PASS A</i> , <i>PASS B</i>
21	PASS A	Relay output <i>PASS A</i> (passage in direction A)
22	PASS B	Relay output <i>PASS B</i> (passage in direction B)
23	READY	Relay output <i>READY</i> (readiness of the turnstile)
24	DET OUT	Relay output <i>DET OUT</i> (state of the intrusion detector)
25	NO A	Normally open contact of the output of external indication control A
26	LIGHT A	Common contact of the output of external indication control A
27	NC A	Normally closed contact of the output of external indication control A
28	NO B	Normally open contact of the output of external indication control B
29	LIGHT B	Common contact of the output of external indication control B
30	NC B	Normally closed contact of the output of external indication control B

31	+12V	Outputs of indication block control of the guide barrier section for direction A
32	LED A	
33	GND	
34	+12V	Outputs of indication block control of the guide barrier section for direction B
35	LED B	
36	GND	
37	U1	PS connection of WD
38	U2	

5.3 Control of the turnstile

The turnstile can be operated from:

- RC-panel (WRC) when the turnstile works as a single stand barrier device,
- ACS- controller when the turnstile works as a part of ACS.



Attention!

In case the turnstile is operated from ACS-controller the RC-panel should be connected to the ACS-controller. The ACS-controller and the RC-panel must not be connected to the turnstile simultaneously.

5.3.1 The RC-panel

The RC-panel (16) is designed as a compact desktop device in a shockproof ABS plastic case with a flexible multicore cable.

The RC-panel serves for setting and indication of the operating modes when the turnstile is manually controlled. The RC-panel overall view is in Fig. 5.

Three buttons on the front panel of the RC-panel are used to set the operating modes. The **STOP** button in the middle is for switching the turnstile into the “Always locked” mode. Light and right buttons **LEFT**, **RIGHT** are for unlocking the turnstile for passage in the corresponding direction.

Above the buttons there are LED indicators of the position of the turnstile rotation mechanism. Red light indicator “*Stop*” means that both directions are blocked. Available commands for control and indication of the RC-panel for pulse and potential control modes are given in Tables 11, 12 and 13.




Figure 5. RC-panel (16) overall view and dimensions

- 1, 2, 3 – buttons **LEFT, RIGHT, STOP** for setting the operating modes;
 4, 5 – green LED indicators “*Left*”, “*Right*”;
 6 – red LED “*Stop*”; 7 – remote control cable

5.3.2 Control modes

Two control modes – pulse and potential – are available. In both control modes the turnstile is operated by input of the commands (i.e. combination of control signals): *Unlock A*, *Stop* and *Unlock B* and special input *Fire Alarm*. Instruction issue algorithm depends upon the chosen control mode.

Setting of the control mode

Either control mode is set by the “*IMP / POT*” jumper on the DIN-rail. If there is no jumper, the turnstile is operated in the pulse control mode, if there is jumper – potential control mode.

Pulse control mode

The pulse control mode is used for control of the turnstile from the RC-panel, a wireless remote control, or via an ACS-controller with outputs supporting pulse control mode.

The minimum input signal duration to change one operating mode for another is 100 ms. The passage waiting time is 5 sec. irrespective of an input signal length.

The turnstile operating modes in the pulse control mode are shown in Tables 11 and 12. The algorithm of control signals is given in Appendix 1.

Potential control mode

The potential control mode is used for control of the turnstile via an ACS-controller with outputs supporting potential control mode.

The minimum input signal duration to change one operation mode for another is 100 ms. The passage waiting time equals a low-level signal duration (the turnstile remains open if upon completion of the passage there is still a low-level signal at the input for the permitted direction).

When a low-level signal is received to the *Stop* input, both directions close for as long as the signal is present, regardless of signal levels at the *Unlock A* and *Unlock B* inputs. When the low signal is removed from the *Stop* input, status of each direction is determined by respective signal levels at the *Unlock A* and *Unlock B* inputs.



Note:

To set a single passage mode in the potential control mode it is recommended to remove a low-level signal from the *Unlock A / Unlock B* inputs and activate relay output *PASS A / PASS B* of the respective direction.

The turnstile operating modes in the potential control mode are shown in Table 13. The algorithm of control signals is given in Appendix 2.

5.3.3 Logic operational sequence in the pulse operation mode

Logic operational sequence in the pulse operation mode in “Single passage” in the set direction:

1. The control device (the RC-panel, the WRC, ACS-controller) sends the incoming command (combination of control signals) to the CU inputs to unlock the passage in the chosen direction.
2. The CU microcontroller processes the incoming combination of signals and generates a command to the turnstile operating mechanism to unlock the rotation mechanism. From this moment the countdown of fixing the turnstile stopper knot in the unlocked position starts.
3. The operating mechanism unlocks the rotation mechanism for rotation in the set direction. The passage in the set direction becomes possible.
4. If the revolving of the rotor does not commence the command to block the rotation mechanism is generated upon the lapse of hold time of the turnstile in the unlocked position (per default – 5 seconds from the moment of the receipt of the command).
5. During the passage the rotation angle of the rotor is monitored by the microcontroller with the help of optic sensors of the control mechanism. When the rotation angle is more than 67° the passage is registered. One of the relay outputs corresponding to the passage direction (*PASS A* or *PASS B*) is activated.
6. For **RTD-20.1** after the rotor turns 12°30' the control unit of the **RTD-20.1** generates a command for automatic rotation in the set direction.
7. When the passage is done and the rotor is in the home position (turn on 120°), the rotation mechanism of the turnstile is blocked. Relay output *PASS A / PASS B* is normalized.
8. The turnstile is ready for the next passage.

5.3.4 Parameters of control signals



Note:

As means of a high-level signal generation at all the input contacts (*Unlock A*, *Stop*, *Unlock B*, *Fire Alarm* and *Detector*) the control unit uses 1-KOhm resistors wired to the power supply bus + 5 V.

Standard control inputs: connectors 9...11 DIN-rail (*Unlock A*, *Stop* and *Unlock B*).

Special control input: connector 6 DIN-rail (*Fire Alarm*).

The turnstile is operated by input of a low-level signal relative to the GND contact at the standard control inputs *Unlock A*, *Stop* and *Unlock B*. Either a normally open relay contact or a circuit with open collector output can be used as the control element.

Emergency unlocking of the turnstile is realized by removal of the low-level signal relative to the "GND" contact from the "Fire Alarm" contact. Acting as the control element can be either a normally closed relay contact or an open-collector circuit (see Fig. 6 and 7).

When the low-level signal is on *Fire Alarm* contact:

- in the pulse control mode, the turnstile is "Always locked";
- in the potential control mode, the passage directions switch to the mode selected in accordance with the level of signals on inputs *Unlock A*, *Unlock B* and *Stop*.

Activation of the intrusion detector is realized by removal of the low-level signal relative to the GND contact from the *Detector* input. The control element can be either a normally closed relay contact 7 or an open-collector circuit

The control element should provide the following signal characteristics:

Control element – relay contact:

minimum switched current..... 3 mA

maximum closed contact resistance

(in view of connecting cable resistance)..... 300 Ohm

Control element – circuit with open-collector output:

maximum closed contact voltage

(low-level signal on the control block input)..... 0.8 V




Figure 6. Control elements: normally open relay contacts




Figure 7. ACS control elements: circuit with open-collector output

5.3.5 Operation from the RC-panel

To have the control over the turnstile from the RC-panel (or a wireless remote control) it is recommended to install the pulse control mode (see Sect. 5.3.2). The RC-panel is connected to the contacts of connectors 7...14 on DIN-rail *GND*, *RC Sound*, *Unlock A*, *Stop*, *Unlock B*, *RC Led A*, *RC Stop* and *RC Led B* in accordance with the electric connection layout of the turnstile (see Fig. 25).



Notes:

- The wireless remote control is connected to contacts *GND*, *Unlock A*, *Stop* and *Unlock B* on DIN-rail. Power supply of the wireless remote control is connected to the contacts *+12V* of DIN-rail.
- Control over the turnstile from a wireless remote control is similar to that from the RC-panel. Buttons on a WRC tag will be responsible for the same functions as the RC-panel buttons.




Figure 8. Standard orientation of the RC-panel against the turnstile post (top view, rotors are not shown for clarity)

Standard configuration of the RC-panels towards the turnstile ODs is given in Fig. 8. The connection of RCs to DIN-rails procedure is described in Table 2. If the operator's working place is located on the opposite side of the post then for more convenience it is necessary to interchange the wires from the RC-panel connectable to the contacts *Unlock A* and *Unlock B*, *RC Led A* and *RC Led B* respectively.

Table 2. Connection of wires of RC-panel cable to the contacts of DIN-rails for standard orientation of the RC-panel

Contact	DIN-rail contact № (for OD №1 and №2)	The RC-panel orientation	
		№1	№2
<i>GND</i>	7	black	black
<i>RC SOUND</i>	8	brown	brown
<i>Unlock A</i>	9	white	green
<i>Stop</i>	10	blue	blue
<i>Unlock B</i>	11	green	white
<i>RC Led A</i>	12	yellow	red
<i>RC Stop</i>	13	orange	orange
<i>RC Led B</i>	14	red	yellow

5.3.6 Fire Alarm device

For immediate unlocking of the turnstile in the event of an emergency, an emergency unblocking device (hereinafter – *Fire Alarm*) can be connected to the turnstile (e.g. fire alarm control panel, emergency button or other similar device to send "*Fire Alarm*" signal).

Connection of *Fire Alarm* device is done to the contacts of connectors 6 and 7 of DIN-rail (*Fire Alarm* and *GND*) according to Fig. 25. If the turnstile is not meant to work with an emergency unblocking device, it is necessary to fix a jumper between the contacts. The "*Fire Alarm*" jumper is factory-installed.

When a low-level signal is removed from the *Fire Alarm* input both passage directions are open for duration of the signal removal, all other commands are ignored.

5.3.7 Operation via an ACS-controller

To have the control over the turnstile from the ACS-controller it is recommended to choose the potential control mode (see Sect. 0).

Connection of the ACS-controller to the turnstile is carried out with the cable connectable to the respective contacts of connectors of DIN-rail in accordance with Fig. 25:

- outputs to contacts *GND*, *Unlock A*, *Stop* and *Unlock B*;
- output to contacts *Common*, *PASS A*, *PASS B*, *Ready* and *Det Out*.

5.4 Optional devices that can be connected to the turnstile



Attention!

When connecting any additional devices, account must be taken that the control unit provides the necessary 12 ± 2 V feeding if the total load of all connected devices does not exceed 300 mA.

5.4.1 Signal parameters of relay outputs

Relay “PASS A” (contacts 21 *PASS A* and 20 *Common*), “PASS B” (contacts 22 *PASS B* and 20 *Common*), “Ready” (contacts 23 *Ready* and 20 *Common*), “Detector” (contacts 24 *Det Out* and 20 *Common*) and “Alarm” (contacts 18 *Alarm 1* and 19 *Alarm 2*) have normally open contacts.

The *Common* contact of these relays is not connected to the negative PS of the turnstile. In reset (non-active) state when the power supply is on the contacts of relays “PASS A”, “PASS B”, “Ready” and “Detector” are closed (voltage on relay coil), and contacts of “Alarm” relay are open (no voltage on relay coil). Output stages for “PASS A”, “PASS B”, “Ready”, “Det Out” and “Alarm” – relay contacts with the following signal characteristics (see Fig. 9):

maximum commutation DC voltage.....	42 V
maximum commutation current	0.25 A
maximum closed contact resistance.....	0.15 Ohm




Figure 9. Output stages for “PASS A”, “PASS B”, “Ready”, “Det Out” and “Alarm”

5.4.2 Intrusion detector and siren



Attention!

Installation of the intrusion detector on the turnstile must be carried out at the Manufacturer’s works.

The intrusion detector is connected to the contacts 3...5 (+12V, *Detector*, *GND*) of DIN-rail, and sirens are connected to the contacts 17 and 19 (+12V, *Alarm 2*). The connection layout is given in Fig. 25.

If the turnstile is closed in the “Always locked” mode (Tables 11, 12 and 13) and a signal is received from the intrusion detector, the “Alarm” signal is generated. The “Alarm” signal is disabled after 5 sec., or upon execution of any command received.

The intrusion detector signal is ignored when the turnstile is open for passage in one or both directions, and over 3 sec. after the turnstile is set in the “Always locked” mode.

The intrusion detector current status signal (see Fig. 7). is constantly relayed to the contact 24 *Det Out* of DIN-rail relative to the contact 20 *Common* (see Fig. 25).

5.4.3 Remote light indicators

Remote light indicators can be connected to the DIN-rail connectors 25...30. The “Green Arrow” on the LED display, corresponding to the set passage direction, indicates that the “Light A” (“Light B”) relay is activated (voltage on the relay coil). Output stages for “Light A” and “Light B” are brake-make relay contacts (Fig.10) with the following signal characteristics:

maximum commutation DC voltage	30 V
maximum commutation AC voltage	42 V
maximum commutation DC/AC current	3 A
maximum closed contact resistance	0.15 Ohm




Figure 10. Output stages for “Light A” and “Light B”

5.5 Operational contingencies and feedback

The turnstile is capable of providing feedback on the following operational contingencies:

1. **The rotor is not in the home position in the “Always locked” mode.** For some reason the rotor is not in the home position. In this position it is not possible to activate “Always locked” mode.
2. **Passage duration exceeds the designated limit of 10 sec.** For some reason the passage is not completed (the rotor is not returned to the home position after the start of an authorized passage).
3. **Activation of the intrusion detector in the “Always locked” mode** normally takes place at the attempt of an unauthorized passage attempt (entrance in the control area) (see Sect. 5.4.2).
4. **Electric motor overload longer than 2 sec (for RTD-20.1).** To prevent possible breakage of the motor and electronics the turnstile has overload protection. If the current to the motor exceeds the set limit longer than 2 sec., the control unit removes the control signals from the motor, the force is taken off the rotor and it stops revolving. In 2 sec. the protection is off, the control signals are fed again and the rotor continues revolving.
5. **Four consecutive motor overloads (for RTD-20.1).** If four consecutive motor overloads¹ occur over one reset of the rotor in the home position, the turnstile switches to the emergency mode and the rotor stops. The emergency mode is over either in 20 sec. or once the rotor is in the home position. When the emergency mode is over, the rotor resets in the home position. As there won't be any operating mode reset, the turnstile continues operation as usual.
6. **Optical sensors failure (either rotation or locking device sensors).** To check optical sensors operation, set the turnstile into the test mode and proceed according to the suggested tests (see Sect. 8.8).



Note:

In the event of failure of optical locking device sensor, the rotor is in the home position the turnstile can switch into the overload protection mode.

Each of the above contingencies is reflected by the special *Ready* signal, the buzz signal from the RC-panel and the *Alarm* outputs activation (refer to Table 3 for details).

Table 3. Operational contingencies

№	Contingency	RC-panel audio response	“Ready” output status	“Alarm” output status
1	The turnstile is in the "Always locked" control mode. The rotor is not in the home position.	Continuous buzz signal. The signal is removed once the turnstile is in the home position.	The output is activated. The signal is removed once the turnstile is in the home position.	The output is activated. The signal is removed in 5 sec. after the turnstile is revolved in the home position, or any control command was received.
2	The intrusion detector is active after activation of "Always locked" mode.	No signal.	Not activated.	The output is activated. The signal is removed in 5 sec. after the turnstile is revolved in the home position, or any control command was received.
3	The passage is not completed over the allocated time of 10 sec.	Continuous buzz signal. The signal is removed once the turnstile is in the home position.	The output is activated. The signal is removed once the turnstile is in the home position.	Not activated.
4	Motor overload longer than 2 sec. (<i>RTD-20.1</i>).	No signal.	The output is activated. The signal is removed once the overload is reset.	Not activated.
5	Four consecutive motor overloads during one rotor passage (<i>RTD-20.1</i>).	Continuous buzz signal. The signal is removed in 20 sec. or once the rotor is in the home position.	The output is activated. The signal is removed in 20 sec. or once the rotor is in the home position.	Not activated.
6	Failure of the optical sensors (rotation or locking device sensors).	Audio signals are given in the performance check sequence in the test mode (see Sect. 8.8.2).	Not activated.	Not activated.

6 MARKING AND PACKAGING

The turnstile marked with a label and a sticker that are attached to the inner surface of the cover of the top channel. The turnstile marking contains trademark, contact data of the manufacturer, product and item name, serial number, date of manufacture, supply voltage and power consumption.

On the label there is a connection layout of the turnstile and optional equipment analogous to the one given in Fig. 25.

To have an access to the label and the sticker take off the top channel cover:



Attention!

Pay particular attention when taking off and installation of the top channel cover, prevent it from falling.

1. Turn off the turnstile power supply and power supply of walkway downlights; disconnect the mains.
2. On the bottom side of the top channel there are 6 holes with plastic plugs fixing the cover. Remove these plugs.
3. Unscrew 4 captive screws M5 fixing the top channel cover (see Fig. 20).
4. Gently lift the cover and remove it from the top channel. This action should be performed by two workers!
5. Put the cover on an even and steady surface. If there is a protective canopy the top channel cover can be put on crosspieces of the canopy.

The mounting of the cover is done in the reverse order. At this it is recommended to position PERCo logo above the post with barrier arms.

The turnstile in the standard delivery set (see Sect. 4.1) is packed in 8 transport boxes that protect its components from damage during transportation and storage. The overall dimensions of boxes and their weight in the standard delivery set are given in Table 4.

Table 4. Overall box dimensions

Box №	Qty	Overall box dimensions (L × W × H), cm	Gross weight, kg
1	1	267 × 40 × 33	96
2	1	221 × 21 × 98	98
3	1	221 × 21 × 98	98
4	2	225 × 21 × 98	50
5	2	225 × 21 × 98	50
6	1	222 × 51 × 140	112

7 SAFETY REQUIREMENTS

7.1 Installation safety requirements

Installation of the turnstile should be carried out by qualified personnel only, in strict accordance with this Manual and general safety requirement for electrical and installation work.



Caution!

- Turn off and unplug all power supplies before work.
- Use only serviceable tools.
- Unpacking, installation, moving of the turnstile sections, installation of the top channel, its cover and the rotor should be carried out by at least two persons.
- Use protective gloves to avoid injury.
- Be careful when taking off and on bulky and heavy parts such as the top channel cover, half-couplings, rotor and make extra sure to prevent them from fall.
- Make sure the installation is correct before the first use of the turnstile.

Power supply units and other optional equipment should be used according to safety requirements given in their respective operation manuals.

7.2 Operational safety requirements

Observe general safety requirements for use of electrical equipment.



Caution:

- The turnstile must not be used in conditions different from those given in Sect. 2.
- The turnstile must not be used with supply voltage different from that given in Sect. 3.
- To avoid injuries – do not step or hang on the turnstile barrier arms, do not pass hands or legs between the barrier arms during the turnstile operation etc.

Power supply units and other optional equipment should be used according to safety requirements in respective operation manuals.

8 INSTALLATION

During the turnstile installation follow the safety measures specified in Sect. 7.1.

The installation should be carried out by at least two persons qualified in assembly and electric work.

Proper installation is critical to performance and serviceability of the turnstile. We strongly advise to study this section before installation work, and follow the instructions to the letter. It is recommended to proceed with installation only after thorough reading of this section and study of the assembly & installation film.



Attention!

The manufacturer will not accept liability for any damage to the turnstile or other equipment, or otherwise loss caused as a result of improper installation, and will dismiss any claims by the customer should the installation work be carried out not in accordance with this Operation Manual.

8.1 General recommendations

Mount the turnstile on flat, solid concrete floors (grade 400 or higher, SCS B22.5), stone or similar foundations at least 150 mm thick.

Make sure the mounting foundation is horizontal and flat; the flatness deviation must not exceed 1.5 mm.

For the installation of the turnstile on softer grounds employ a foundation frame **RF-20** or reinforcing elements 500×500×500 mm.



Attention!

During the installation of several turnstiles in line leave a technological 30 mm gap between them to compensate assembly errors, to improve conditions for upper cabling and to provide conditions for assembly of canopies.

To fix the turnstile it is recommended to use the anchor bolts “**SORMAT**” (see Table 5).

Table 5. Required “SORMAT” anchor bolts

Type	Use	Drill diameter, mm	Drill depth, mm	Qty
PFG IR 10-15	To fix sections (6) of the guide barrier set and divider sections post (5)	16	60	24
PFG IR 16-25	To fix the bottom rotation unit (3)	25	100	2
PFG IR 10-15	To fix cable duct for cable grooming from the bottom	16	60	2

Assembly of the power supply units and other optional equipment should be carried out according to the requirements given in operating documentation to the equipment.

8.2 Tools and equipment required for assembly



Note:

Use of other similar tools is allowed providing they do not reduce quality of the installation work.

It is recommended to use the following tools and equipment for the installation work:

- electric perforator 1.2÷1.5 kW;
- screw gun;

- carbide drill bits Ø16 mm and Ø25 mm;
- socket key S17;
- hex-nut wrenches SW1.5; SW3; SW4; SW6; SW8; SW14;
- №2 cross-tip screwdriver, 150 mm;
- №5 straight- slot screwdriver, 150 mm;
- pair of trammels;
- 3 m tape measure;
- level gauge;
- dynamometer up to 10 kgf;
- 0.5 mm × 2.5 m wire (pull-out wire);
- adhesive tape (Scotch);
- two stepladders (4 steps or more).

8.3 Allowable cable lengths

Cables used for installation are given in Table 6.

Table 6. Cables used for installation

№	Pluggable equipment	Max cable length, m	Cable type	Cut, mm ² , not less than	Example
1	Power source unit	10	Double-core	1.5	AWG 15; 2×1.5 two-color
		15	Double-core	2.5	AWG 13; 2×2.5 two-color
2	- Fire Alarm device - Optional equipment connected to inputs or outputs	30	Double-core	0.2	RAMCRO SS22AF-T 2×0.22 CQR-2
3	RC-panel	40	Eight-core	0.2	CQR CABS8 8×0.22c
4	ACS-controller	30	Six-core	0.2	CQR CABS6 6×0.22c

8.4 Installation of the turnstile

Description of installation operations is given in accordance with recommendations listed in Sect. 8.1. The connection scheme for the turnstile and additional equipment is given in Sect. 8.9. Follow this continuity of actions while installing the turnstile and optional equipment:

1. Install PS of the turnstile and if necessary PS of walkway downlights in designated locations and connect the power cables.
2. Prepare the mounting surface.
3. Mark out on the mounting surface mounting holes for the turnstile installation. Use template for markup, check the dimensions in accordance with Fig. 11.



Note:

Together with marking for the turnstile installation it is required to mark out the mounting holes for installation of other elements of access point mounted together with the turnstile: full height barrier sections **MB-16** and full height gate **WHD-16** (see Appendix 3).




Figure 11. Mounting hole pattern

4. If the special cable duct (included in the standard delivery set) will be used for bottom cabling, then it is necessary to mark the fixing holes and cable channels on the mounting surface in accordance with the scheme shown on Fig. 30.



Note:

Material, configuration, dimensions, wiring type (surface, buried, combined), position at the entrance point and other characteristics of the electric raceways are chosen by the customer in accordance with the entrance point features and layouts, other operational factors.

5. Mark out mounting holes and cable ducts. Through cable ducts lay necessary power cables (15), cables of *Fire Alarm* devices (17), RC-panel (16) and optional equipment.
6. Install anchor bolts for the whole depth of prepared holes.



Attention!

Be extra cautious and careful when carrying out further work on fixing the top channel. Prevent the turnstile parts from falling.

7. Unpack divider sections (5) and top girder (8) (box №6).
8. Install the divider (operation should be performed by at least two persons!):
 - Erect both divider sections (5) on the mounting surface so that the holes of supporting flanges coincide with the positioning of anchor bolts.
 - Fix the sections on the mounting surface with anchor bolts M10×50. Anchor the sections but not tightly, so that you can make the adjustment.
9. Install the divider top girder in divider sections posts and fix them with the screws M5×12 (8 pcs.), that are included in the installation kit (Fig. 12).
10. Unpack the lower support of rotors (11) (box №6) and place it on the fixing holes with M16 anchor bolts (Fig. 13). Unpack the bottom bearing rotation units the bottom bearing rotation units (3) (inserted in the lower support). Insert supporting flanges of the rotation unit into the relevant places of the support and fix the lower support on the

mounting surface with the two M16×60 anchor bolts with washers (not included in the standard delivery set).

11. Assemble the bottom bearing rotation units (3) in the supporting flanges of the lower support (Fig. 14). Two slip washers and the fluoroplastic insertion placed between them must be situated in the assembly unit avoiding any misalignment and rest on the entire bearing surface symmetrically in respect to the rotor axis (the top thrust washer is glued to the rotor shaft). Herewith, the smooth surfaces of slip washers must be directed at the insertion. The slipping surfaces may be treated with molybdenum grease.
12. Unpack sections of guide barrier set and supporting girders (boxes №4 – left sections and supporting girders, boxes №5 – right sections). Open box №6 and retrieve a bag with assembly and mounting tools.
13. Install the guide barrier sections (operation should be performed by at least two persons!):
 - Erect the guide barrier sections (6) on the mounting surface so that the holes of supporting flanges coincide with the positioning of anchor bolts. Left and right sections should have right positioning and orientation: indication blocks of the guide barrier sections should be turned out of the axis of symmetry (see Fig. 2) consider the positioning of the support post fixing points on the sections (see Fig. 15).
 - Fix the guide barrier sections on the mounting surface with anchor bolts M10×50. Anchor the sections but not tightly, so that you can make the adjustment.
14. Install the supporting girder (7) on the guide barrier section (6) (see Fig. 15):
 - Position the square hole in the middle part of the post upwards. Bring indication cables from the guide barrier section through the supporting girder and lead them in the central square hole of the supporting girder.
 - Fix the supporting girder on the guide barrier sections by four screws M8×16 (wrench SW6) from the set of assembly tools (box №6). When installed outside it is recommended to seal the fixing zone with a weather resistant silicon sealant to ensure reliable operation of the module.




Figure 12. Installation of the top girder of the divider




Figure 13. Fixation of the lower support on the mounting surface




Figure 14. Bottom rotation unit




Figure 15. Fixing of the supporting girder to the barrier sections

15. Unpack the top channel (9) with the cover (10) (box №1).

16. Assemble the top channel (9) (performed by 2 persons minimum!):

- Take off the cover (10) from the top channel (as indicated in Sect. 6).
- Using two stepladders, lift the top channel and lean it above the turnstile so that stud-bolts installed in the guide barrier sections (6) get into the corresponding wholes of the channel. Do not damage the connecting cables!
- Holding the channel, lift it from the one side and lay the cable ends through the corresponding wholes of the top channel: indication cables (14) through the supporting girder (7). Temporary fasten them inside the channel (for example, with the tape). Repeat the assemble procedure from the opposite side of the top channel.
- Fix the top channel to the guide barrier sections with four nuts M10 with washers (Fig. 16), using the socket wrench S17. Do not tighten the nuts for later adjustment.
- Fix the top channel to the supporting girders (7) and to the top girder of the divider (8) with six bolts M8×25 and the key SW6, using two plates from the delivery set (Fig. 17). Do not tighten the bolts for later adjustment.




Figure 16. Top channel to barrier section fastening




Figure 17. Top channel to supporting girder fastening

17. Mount the OD rotors (1) (Don't work alone!), each in the following order:

- Unpack rotor sections (1) (box №2 – rotor 1, box №3 – rotor 2).
- Use cylindrical shank to install the rotor section with mounting parts in the bottom rotation unit (3) (Fig. 14), first bring it into the unit at a slight angle to the surface, then turn it into the vertical position.
- Adjust the rotor section in accordance to the selected passage mode (Sect. 8.5, Fig. 22) given the match of the edges of upper rotor shaft and the edges of drive shaft.
- Join together the upper rotor shaft with the shaft of the drive unit of operating device with two half couplings, four bolts M8×30 and spring washers (hex-nut wrench SW6) (Fig.18). Be careful, half couplings are very heavy, do not drop them to avoid injuries!
- Fasten successively the two remaining sections to the attachment points of the section installed using 4 bolts M8×14 for upper mounting points and 20 bolts M8×12 (wrench SW6) for the rest of the attachment points with spring washers (Fig. 19). It is recommended to use the tool that adheres to the bolt being tightened, for instance, use the tool with a magnet tip for the works on the steel rotor. Stainless steel bolts are applied for the stainless steel rotors, in this case a sticky tape wrapped around the tip of the tool or some other ductile materials are advised to be used.
- At the end of the assembly check the gaps between the sections that are to be even in comparison to each other distributed; tighten the rotor bolts after that.




Figure 18. Juncture of the operating mechanism shaft with the rotor shaft by the union joint





Figure 19. Juncture of the rotor sections

- Check the verticality of the rotor position with level. Eliminate the deviations if necessary by means of shifting the top channel where it is possible while not obscuring the installation holes for bolts and stud-bolts. Make the final tightening of bolts and nuts at the top channel assembly points.
 - Unlock the mechanical locking system of the turnstile with the keys and check the rotor rotation quality. The rotation is supposed to be uniform and require similar force to be applied to it during the push for each direction; there should be no binding or squeaking.
18. Make the final tightening of bolts and screws of all the parts of the turnstile. In case of skewing in between the load-bearing elements of the turnstile, assembly gaskets are to be used.
19. Check the verticality of the rotor position with the level once again. Verify the extent of free rotation of the wing panel. The force applied to the center of the wing panel shouldn't exceed 3 kgf. The center of the wing panel is adopted to be the center of the fifth barrier arm when counted from the bottom up. The force can be measured by dynamometer or a spring balance. In case of discrepancy it is necessary to examine the adjustment, assembly of the turnstile and rotor as well as the lower rotation unit.
20. Use the plastic plugs Ø16 to cover the bolt holes in the joints connecting the rotor section (2) and supporting girder (7) to the section (6) of guide barriers set (Fig. 15 and 19).
21. Power and control cables grooming from the top side through the end surface of the top channel: Extract the necessary amount of plugs from the protective insertion panel, insert the cable bushings in the vacant holes and pull the cable through the bushings into the top channel.
22. Use the channel from the delivery set in order to lay out the cables atop to connect turnstiles standing close to each other (Fig. 21). Remove the protective inserts prior to the installation of the channels, unscrew two M4 screws (SW3 key). The larger channel should be located above.
23. Power and control cables grooming from below through the special cable duct (included in the standard delivery set):
- put bottom end of the cable duct towards the cable outlet on the mounting surface and pull a cable into the duct;
 - take off the protective insert (Fig. 20), unscrew the two M4 screws (SW3 key), that holds it from the top;
 - mount the cable duct – place the bottom end atop of the holes with anchor bolts in the mounting surface and the top end to the location of the protective insert – pull the cables into the top channel;
 - fix the cable duct by two M4 screws from the top and two anchor bolts from the bottom side.
24. Perform the link-up to the contacts of the DIN-rail in accordance to the following turnstile and accessories connection scheme (Fig. 25):
- indication cables (14), use self-adhesive cable tie mounts in its places;
 - turnstile power cables (15);
 - the cables of RC-panels (16) or the WRC units;
 - the cable for the *Fire Alarm* unit (17) (in case the *Fire Alarm* unit isn't the part of the package, make sure the «*Fire Alarm*» jumpers is in its places);
 - jumpers «*IMP / POT*» DIN-rails (on contacts 15 and 16 of the DIN-rail) – for the potential control mode;
 - cables for the accessories (if present).



Top channel - bottom view




Figure 20. Top channel elements




Figure 21. Cable laying between two turnstiles

25. Verify the correctness and reliability of the electric linkage in accordance to the scheme of connection of turnstile and accessories (Fig. 25).
26. Stow the cables carefully inside the top channel upon the brackets, fix the cables with the brace rod from the delivery set. The cables shouldn't interfere with the functioning of operating device and obstruct the shutting of the top channel's cover.
27. For the unmotorized model of **RTD-20.2** turnstile one can perform regulation of the damper if necessary (see Sect. 8.6).
28. Place the cover (10) upon the top channel (9):
 - Lift the cover gently and put it upon the top channel from above. This procedure should be accomplished by two installers. If the turnstile has a canopy, the top channel's cover may be temporarily placed upon the transverse parts of the canopy.
 - Screw six captive screws M5 (wrench SW4) up, the screws are fixing the cover of the top channel (Fig.20).
29. Switch the mechanical unlock system of the turnstile off (see Sect. 9.4).
30. Turn the turnstile on in accordance with Sect. 9.1. Perform the verification of the turnstile's operability in test mode using the remote control in accordance with Sect. 8.8.

The turnstile is installed and ready for operation.

8.5 Selection of the passage mode

Keep in mind the level of control requirements at the checkpoint, the intensity of the turnstile usage, the design of the checkpoint and other operation factors while choosing the turnstile passage mode (see Tables 11 and 12).

The passage mode depends on the rotor position when the turnstile is in its home (closed) condition. There are two ways the wing panel blocks the passage zone while in home position of the turnstile that defines possible passage modes:

- **Standard mode** (Fig. 22a). In the home position the passage zone is blocked by one turnstile wing panel. The standard mode of passage through the turnstile is recommended to be used when there are no particularly rigid requirements to the checkpoint access control.
- **Lock-chamber mode**¹ (Fig. 22b). While the turnstile is in home position the passage zone is blocked by two wing panels forming the lock-chamber which is the part of the passage through the turnstile limited by the sections of guide barriers set and two turnstile wing panels. The lock-chamber allows organizing reinforced control over the access to a secured area. The lock-chamber mode is particularly effective for the passage management at the checkpoints of secured facilities, special institutions and other sites with specific requirements to access control.

Selection of the passage mode is defined by the orientation of the rotor shaft at the time of its installation in the process of the turnstile mounting (see Sect. 8.4). Further switching from the standard to the lock-chamber mode and vice-versa depends on the particularity of the turnstile usage and is possible by means of reinstallation of the rotor.

Follow these steps in order to reinstall the rotor when necessary (Don't work alone!):

1. Lock the rotor in the initial position. Switch the PS off and unplug them from the mains.

¹ Operation of the turnstile in the ACS in the lock-chamber mode is possible only if the ACS-controller supports this mode.

2. Unscrew 4 bolts M8 from the union joint (4) and take off the half couplings (Fig. 18), Be carefully! Keep the rotor and half couplings from falling down.
3. Rotate the rotor 180° (Fig. 22).
4. Join the rotor shaft with the shaft of the operating device with half couplings.
5. Tighten the bolts constricting the half couplings.
6. Perform the mechanical release of the turnstile (see Sect. 9.4) and verify that the rotation of the rotor is unobstructed; return the turnstile wing panels to their home position.
7. Perform the mechanical blocking of the turnstile.
8. Switch the turnstile on in accordance to the Sect. 9.1.




Figure 22. Home position of the turnstile wing panels (the view from above):
a – standard mode, b – lock-chamber mode

8.6 Adjustment of damper device RTD-20.2



Attention!

The correctly adjusted damper device provides almost shockless closure of rotor wing panels when they are reset to home position. The unadjusted damper of the turnstile may cause a breakdown of its parts and lead to the necessity of repair works.

The damper device (hereinafter damper) is the part of the operating device of the turnstile model type **RTD-20.2** with the resetting mechanism. The damper is designed to provide smooth and shockless rotor stopping at the end of its automatic reset.

Damper adjustment frequency:

- during the turnstile installation prior to operation;
- during the operation when technical maintenance of the turnstile is performed (see Sect. 10).
- during the considerable changes of temperature conditions of the turnstile operation when used outside, such as during the transition from summer to winter time service and vice-versa.

8.6.1 The damper device operation check

Follow these steps before the damper adjustment:

1. Switch the PS's off and unplug them from the mains.
2. Accomplish the mechanical release of the turnstile OD (see Sect. 9.4).
3. Make sure that the wing panels are unlocked by turning the rotor both directions for several times.
4. Turn the wing panel slowly from its original (closed) position in either direction so that its deviation from this position would form a more than 60-degree angle, stop shortly before the automatic reset.
5. Release the wing panel and let the rotor finish the rotation by means of automatic reset. During the automatic reset pay attention to how does the rotation and the halt of the wing panel go:
 - if at the end of the automatic reset the wing panel reaches its home position with considerable speed and while first skipping it the panel then returns back and oscillates around its home position for several times – the adjustment should be aimed at increasing the damper force;
 - if after an inconsiderable skip the rotor smoothly returns to its home position – the damper adjustment is not required;
 - if during the automatic reset the wing panel moves with obviously excessive slowdown – the adjustment should be aimed at decreasing the damper force.

The damper is believed to be properly adjusted if it satisfies the following requirements. The speed of the wing panel rotation during the automatic reset approximately matches the average comfortable speed of a person passing through the turnstile. At the end of the automatic reset the wing panel approaches its home position with smooth slowdown while having no backward motion or considerable oscillation around its home position during the halt.

8.6.2 The damper device adjustment order

1. Remove the cover (10) from the top channel (9) (see Sect. 6).
2. Unscrew the locking screw of the damper's adjusting screw with the hex-nut wrench SW1.5, the locking screw is situated at the end face of the adjusting screw (Fig. 23).



Note:

- The damper is preliminarily preset for the summer time operation (the scale position of the adjusting screw is set to 5) normally the readjustment of the damper is not required when operated under -5°C to $+45^{\circ}\text{C}$ temperature conditions.
- For the satisfactory operation of the turnstile below -5°C the damper loosening (the increase of the spring tension of the resetting mechanism) is necessary.

3. Depending on what adjustment is needed turn the adjusting screw of the damper accordingly:
 - clockwise till the point 7 if the increase of the damping force is required,
 - counterclockwise till the point 3 to decrease the damping force.
4. Repeat the check of the damper operation in accordance to the Sect. 8.6.1.
5. If necessary, repeat the correction of the position of damper *adjusting screw* by means of rotation. Achieve the optimal resetting speed of the turnstile rotor.
6. Depending on the conditions of use the necessity of the rearrangement of lever springs may appear. The rearrangement should be also consulted with the point 3

mentioned above. The goal to be achieved here is to increase or decrease the force of tension of the lever springs which translates into increase or decrease of the resetting speed of the turnstile rotor.



Attention!

During the rearrangement of lever springs, it is recommended to start with the removal of the spring hook in order to avoid the danger of injuries.

7. At the end of the regulation fix the position of the damper adjusting screw with the locking screw.
8. Install the cover upon the top channel (see Sect. 6).
9. Accomplish the mechanical locking of the turnstile OD (see Sect. 9.4).
10. Switch the turnstile OD on in accordance to the Sect. 9.1.




Figure 23. The turnstile damper RTD-20.2

8.7 Replacement of walkway downlights

If necessary, the replacement of walkway downlights is done in the following order (see Fig. 20, 24):

- turn off the turnstile power supplies and disconnect them from the mains;
- remove the top channel cover (see Sect. 6);
- in the top channel, remove the installation fixture for the walkway downlights by unscrewing four M4 screws (screwdriver PH2);
- replace the walkway downlights and screw the installation fixture into place;
 - Check the connection of the walkway downlights and the power cable of the walkway downlights to the terminal blocks and the DIN-rail in accordance with the connection layout (see Fig. 25).



Note:

To illuminate the passage, only 5W / 12V LED lamps with GU-5,3 MR16 socket or equivalent are used. Do not use halogen lamps!




Figure 24. Walkway downlights with the installation fixture

8.8 The turnstile performance check

Check the operation of each OD of the turnstile separately (sect. 8.8.1, 8.8.2). Check the operation when several people pass simultaneously through both ODs of the turnstile.

8.8.1 Verification of the mechanical and emergency unblocking of the turnstile

1. Test the functioning of the mechanical release locks separately for both passage directions.
2. Put the rotor of the turnstile to home position. Switch the turnstile on (see Sect.9.1).
3. Examine the functioning of the mechanical release sensors. Open the mechanical release lock for one of the passage directions and check the changes of light indication, the green arrow sign should appear at the indicator and be pointed towards the direction unlocked. The remote control panel led situated above the stop button should go out while the led above the button corresponding to the direction unlocked should light up. Perform the same sensor examination for the other passage direction.
4. Open both mechanical release locks and check the capability of turnstile rotation in different directions. Herewith the motorized version can reset the wing panels to home position automatically.
5. Close the mechanical release locks, it will block the turnstile rotation both directions. The indication will return to original condition, the indication situated at the turnstile post will show the red cross, the remote control panel will have a red led glowing above the stop sign.
6. Send a signal from the *Fire Alarm* device or disconnect the jumper between the clips 6 and 7 of the DIN-rail to check the performance of the *Fire Alarm* emergency unlock system. In this case the turnstile will become unlocked for the rotation in both directions; the indication of the remote control panel will correspond to the point 8 of the Table 7.

8.8.2 Verification of the turnstile performance in test mode

The verification is accomplished by means of pulse mode control of the turnstile exercised with the remote control panel.

1. Make sure the turnstile is mechanically locked against rotation in both directions (see Sect. 9.4).
2. Switch the turnstile on in accordance to Sect. 9.1. The RC-panel will emit a single audible signal during the turnstile activation.
3. Press briefly all three buttons at the remote control panel in order to switch the turnstile to the test mode. In this case the RC-panel (remote control panel) will emit a single audible signal, the order of RC-panel indication lights will be in accordance with the point 1 of the Table 7.
4. After the turnstile is switched to the test mode the order of RC-panel indication lights will be in accordance with point 2 of the Table 7.
5. Push the left button (button **LEFT**) at the RC-panel. This will unlock the turnstile gates for the passage in the direction A, in this case the order of RC-panel indication lights will be in accordance to the point 3 of the Table 7. The electronics of the board will check whether the signals from this passage direction match. If the RC-panel doesn't emit any audible signal in 10 seconds, then the sensors are in proper condition. In case the signals appear from the RC-panel buzzer, the faulty sensor can be found in accordance to the Table 8.
6. Turn the rotor of the turnstile in the direction unlocked to a 15° angle, in this case the rotor will shift to the next position while RC-panel buzzer will produce a signal in accordance to the Table 9. Monitor the correspondence of the number of audible signals and the rotor position in accordance to the Table 9 while turning the rotor to a 360° angle. Press the **STOP** button at the RC-panel.



Note:

If there is more than a one audible signal, it stands for unnormalized condition of one of the sensors. In this case it is recommended to apply to the nearest service center of **PERCo** for the advice.

7. Press the button **RIGHT** at the RC-panel and accomplish the same examination for the direction B. In this case the light indication of the RC-panel will correspond to the point 4 of the Table 7, and the sound signal order should correspond to the Table 9.
8. Press the **STOP** and **LEFT** buttons at the RC-panel at the same time.
7. **For RTD-20.2.** Turn the rotor in the direction A to a more than 50° angle, the following behavior should be supervised:
 - the RC-panel indication should correspond to the point 5 of Table 7;
 - the variation at the outlets *PASS A(B)* must correspond to the ongoing turn of the rotor;
 - the rotor must make a reset towards the passage;
 - continuous audible signal from RC-panel and the *Ready* signal tell about the absence of changes of signals from the turn sensors over a period of 10 seconds and about malfunction of the turn sensors chains accordingly.

For RTD-20.1. The rotor of the turnstile will start a continuous rotation in the direction A, the following behavior should be supervised:

- the RC-panel indication should correspond to the point 5 of Table 7;
- the variation at the outlets *PASS A(B)* must correspond to the current turn of the rotor;
- the direction of the rotor rotation must correspond to the set direction;
- the rotor has to be rotating smoothly and without jerks;

- continuous audible signal from RC-panel and the *Ready* signal tell about the absence of changes of signals from the turn sensors over a period of 10 seconds and about malfunction of the turn sensors chains accordingly.
9. Accomplish the same examination for the direction B. In this case the light indication of the RC-panel must correspond to the point 6 of Table 7.
 10. Press the **STOP** button at the RC-panel at the end of examination.
 11. Quit the test mode by switching the turnstile off and on again.

Table 7. Button positions and indication on the RC-panel subject to a control command¹

№	Control command	RC-panel status						
		Buttons			Buzzer	Lights above buttons		
		L	STOP	R		L	STOP	R
1	Initiation of the test mode	+	+	+	+	G	R	G
2	Reset state	-	+	-	-	-	R	-
3	Unlocking L direction	+	-	-	+	G	R	-
4	Unlocking R direction	-	-	+	+	-	R	G
5	Rotation in L direction	+	+	-	+	G	-	-
6	Rotation in R direction	-	+	+	+	-	-	G
7	Leaving the test mode	+	+	+	+	G	R	G
8	Fire Alarm ON	-	-	-	-	G	R	G

Table 8. Sensors test

Number of buzzing signals from the RC-panel	Sensors operational status
1	All sensors operational
2	Left optical rotation sensor (SPL)
3	Right optical rotation sensor (SPR)
4	Left optical sensor of the locking device №1 (SZL1)
5	Left optical sensor of the locking device №2 (SZL2)
6	Right optical sensor of the locking device №1 (SZR1)
7	Right optical sensor of the locking device №2 (SZR2)

Table 9. Correlation between the RC-panel audio signals and position of the rotor²


Number of buzzing signals from the RC-panel	Position of the rotor
1	Reset state
2	12°30' angle towards R or 85° towards L
3	50° angle towards R or L
4	85° angle towards R or 12°30' towards L


¹ In Table 8: + – a brief push of a button, an audio signal (buzzer); G – green light is on; R – red light is on.

² Number of audio signals correlates with a current position of the rotor. The audio signals sound when the rotor turns into next position.

We advise to contact PERCo Technical Support Department in the event of any malfunction.

8.9 Turnstile and optional equipment connection layout





* Not included in standard delivery set

Figure 25. Turnstile and optional equipment connection layout¹

Table 10. Layout components list

Legend	Item	Qty
A1	Turnstile RTD-20	1
A2	Top channel	1
A3.1, A3.2	RC-panel (№1 and №2)	2
A4.1*, A4.2*	WRC (№1 and №2)	2
A5.1*, A5.2*	ACS-controller (№1 and №2)	2
A6.1*, A6.2*	Turnstile PS (№1 and №2), +24V / 5,5A	2
A7*	<i>Fire Alarm</i> – Emergency unlocking device	1
A8.1*, A8.2*	ID (№1 and №2)	2
A9*	Siren, +12V	1
A10.1*, A10.2*, A11.1*, A11.2*	Remote indicators for directions A and B (for OD №1 and №2)	4
A12.1*, A12.2*	PS of remote indicator units	2 (or 1)
A13*	PS of walkway downlights, +12V / 3A	1
WD	Walkway downlights - 16MP-5LED (2700K, cap GU5.3)	4
LED A, LED B	Indication units for directions A and B (for OD №1 and №2)	4
RA*, RB*	ACS readers for directions A and B (for OD №1 and №2)	4
XP1...XP38	Connectors MVK4 on DIN-rails (for OD №1 and №2)	76
1*, 2*	Indication cables for directions A and B (for OD №1 and №2)	4
3*	Power cables for OD (№1 and №2)	2
4*	External WD power cable	1
5	Wire jumpers «IMP / POT» (for OD №1 and №2). At delivery the jumpers are off, the pulse operation mode is on	2
6	Wire jumpers <i>Fire Alarm</i> (for OD №1 and №2), are connected in case there is not emergency unlocking device A7. At delivery the jumper is off.	2
7	Internal WD power cables (for OD №1 and №2)	2



Notes:

1. Elements that are marked with (*) sign, are not included in the standard delivery set.
2. Provided diagram corresponds to the standard RC-panel orientation towards the turnstile (see Sect. 5.3.5).
3. Both ODs should be connected in series to the one output of the *Fire Alarm* device (see Sect. 5.3.6).

¹ Layout components list is given in Table 10.

9 OPERATING THE TURNSTILE

Observe safety requirements listed in Sect. 7.2 during the turnstile operation.



WARNING! It is prohibited:

- To move through the turnstile passage area any objects with dimensions exceeding the width of the passageway.
- To jerk or hit the turnstile parts.
- Dismantle and/or adjust operational units of the turnstile (the operating mechanism and the CU).
- To use cleaning substances that can cause damage or corrosion of the turnstile parts.

9.1 Starting procedure

Stick to the following starting procedure:

1. Make sure the barrier wings are in the reset state, according to the chosen access mode (see Sect. 8.5).
2. Use the keys to check if the mechanical release locks are closed (the turnstile is locked mechanically, see Sect. 9.4).
3. Connect power supply units of the turnstile and walkway downlights to the mains with voltage and frequency given in their respective specifications.
4. Switch on the power supply.



Note:

If the turnstile is working correctly the RC-panel will produce an audio signal. The multiple signals are produced if one of the sensors is faulty (see Table 8).

5. In 4 seconds after the power supply units are switched on, the turnstile switches to the "Always locked" mode. On both indication blocks (13) the red light indicators will be on. On the RC-panel (16) the red light above "STOP" will be on.
6. In case of installation check performance of the ID and the siren as given below:
 - In 10-50 seconds after the turnstile power supply is switched on (when the test indicator inside the ID is off) bring a hand to the ID.
 - When ID is activated you will hear a continuous siren signal. The signal is removed either automatically in set time (5±0.5 seconds) or once any button on the RC-panel is pressed.
7. Check performance of the turnstile in all operating modes as given in Tables 11, 12 and 13 depending on the controlling device and function characteristics of the operating mechanism.
8. Once the checking is completed the turnstile is ready for operation.

9.2 Pulse control mode

Issuing of commands for the turnstile operation from RC-panel and indication of these commands are exercised in accordance to the Tables 11 and 12. The passage directions are controlled separately, that is the issuing of the command for one of the two directions does not affect the state of the opposite passage direction. The button markings and light indicators of the RC-panel are shown at the Fig.5.



Note:

Press of the RC-panel button corresponds to the issuing of the low level signal (in relation to GND contact) to the contacts of DIN-rail (*Unlock A, Unlock B* and *Stop*).

Specifics of the signal issuing:

- After the issuing of the command «*Single passage in set direction*» the turnstile automatically blocks the passage direction after one-time passage is made. If the passage through is not made the turnstile performs automatic self-closure after the expiration of the time of holding in unlocked state (5 seconds default).
- After the issuing of the command «*Bidirectional single passage*» and making the passage in one direction only, the countdown of time of holding in unlocked state for the other direction resumes.
- After the issuing of the command «*Single passage in set direction*» such commands as «*Free passage*» or «*Passage denial*» can be sent for the same direction.
- Only the «*Passage denial*» can be sent after the issuing of the command «*Free passage in set direction*».

Table 11. Standard operating modes. Operation in the pulse control mode (the «IMP/POT» jumper is off)

Operating mode	Action ¹	Indication		Status of the turnstile
		on the RC-panel	LED indication	
“Always locked”	Press the STOP button	Red light above the “Stop” button.	Red Cross for both directions.	The rotor is locked in the home position; the passageway is closed by one of the barrier wings.
“Single passage in the set direction”	Press the button LEFT (RIGHT) for the chosen passage direction	Green light above the button responsible for the chosen passage direction “Left” (“Right”) red light above the “Stop” button.	Green Arrow for the open passage direction, Red Cross for the opposite direction.	The rotor can be revolved 120 ° once in the set direction.
“Bidirectional single passage”	Press simultaneously both LEFT and RIGHT	Two green lights above the side buttons “Left” and “Right” red light above “Stop” button.	Green Arrow for both passage directions. After a single passage in each direction Red Cross indicator is on.	The rotor can be revolved 120° once in one direction, then once in the opposite direction, then both directions are blocked in sequence.
“Free passage in the set direction”	Press simultaneously two buttons STOP and LEFT (RIGHT)	Green light above the button responsible for the chosen passage direction “Left” (“Right”)	Green Arrow for the chosen passage direction, Red Cross for the opposite direction.	The rotor can be revolved many times in the chosen direction until the command is changed.
“Always free”	Press simultaneously all three buttons: LEFT, STOP and RIGHT	Two green lights above the side buttons “Left” and “Right”.	Green Arrow for both passage directions.	The turnstile is open; the rotor can be revolved many times in both directions.

¹ The turnstile operation with the WRC is similar to the operation from the RC-panel. Buttons on the RC tag transmitter have the same functions as the WRC buttons.

Table 12. Lock-chamber operating modes. Operation in the pulse control mode (the «IMP/POT» jumper is off)

Operating mode	Actions	Indication		Status of the turnstile
		on the RC-panel	LED indication	
“Always locked” (the turnstile is closed for entry and exit)	Press the STOP button	Red light above the “Stop” button.	Red Cross for both directions.	The rotor is locked in the home position. The passageway is closed by two barrier wings forming the lock-chamber.
“Lock-chamber two-phase access” (the turnstile is open for single two-phase passage in the chosen direction, closed in the opposite direction)	1st phase (entry): Press the button LEFT (RIGHT) responsible for the chosen passage direction	Green light above the button responsible for the chosen passage direction “Left” (“Right”) red light above the “Stop” button	Green Arrow for the chosen passage (entry) direction, Red Cross for the opposite direction.	The rotor can be revolved 120° once in the chosen passage (entry) direction.
	2nd phase (decision making: access granted – the entrant can exit “the lock chamber” in the initial passage direction; access denied – the entrant has to return in the opposite direction): Press the button responsible for the decided passage direction	Green indicator above the button responsible for the decided direction of exit, red light above the “Stop” button.	Green Arrow for the chosen passage (entry) direction, Red Cross for the opposite direction.	The rotor can be revolved 120° once in the direction of exit from “the lock-chamber”
“Free passage through “the lock-chamber” in the set direction”	Press simultaneously the STOP button and the button responsible for the chosen passage direction LEFT (RIGHT)	Green light above the button responsible for the chosen direction “Left” (“Right”).	Green Arrow for the chosen passage direction, Red Cross for the opposite direction.	The rotor can be revolved many times in the chosen direction.
“Free passage through “the lock-chamber” in both directions” (the turnstile is open for multiple passage in both directions)	Press all three buttons LEFT, STOP and RIGHT simultaneously	Two green lights above the side buttons “Left” and “Right”.	Green Arrow for both passage directions.	The turnstile is open; the rotor can be revolved many times in both directions.

9.3 Potential control mode

The procedure of issuing of the turnstile control commands from ACS and the indication of the commands during the potential control mode is implemented in accordance to the Table 13. The passage directions are controlled separately, that is the issuing of the command for one of the two directions does not affect the state of the opposite passage direction.

In case of presence of the low-level signal at the contacts of corresponding passage direction which is being passed through at the moment, the turnstile will keep this direction open.

Table 13. Potential control mode (the «IMP/POT» jumper is on)

Operating mode	Actions	Indication	Status of the turnstile
«Always locked»	The high-level signal at <i>Unlock A</i> and <i>Unlock B</i> contacts or the low-level signal at the <i>Stop</i> contact.	Red indicators for both directions are on.	The rotor is locked in original position.
«Free passage in the set direction»	The low-level signal at the contact of set direction. The high-level signal at the rest of the contacts.	Green indicator for set direction and red indicator for the opposite direction are on.	The rotor is unlocked for rotation in set direction until the command change.
«Bidirectional free passage»	The low-level signal at <i>Unlock A</i> and <i>Unlock B</i> contacts and the high-level signal at <i>Stop</i> contact.	Green indicators for both directions are on.	The rotor is unlocked for the rotation in both directions until the command change.

9.4 Emergency actions

For the emergency evacuation of people from the enterprise in case of fire, natural disaster or other alarm conditions, an emergency exit is required. Such an exit can be arranged by the full-height swing gate **WHD-16**.

The passage zones of **RTD-20** can serve only as an additional emergency exit. In this case the turnstile rotor has to be unlocked in order to provide free passage.

The turnstile can be unlocked by means of:

- control signal sent from the emergency unlock *Fire Alarm* device (see Sect. 5.3.6);
- unlocking the mechanical locks (used during electric grid power fluctuation or due to PS function failure etc.).

Take the following steps in order to unlock the turnstile mechanically:

1. Insert the key into the lock of mechanical unlocking situated at the side of the turnstile towards which the passage direction is to be unlocked.
2. Open the lock with the key by making one complete turn counterclockwise.
3. If the turnstile is switched on, then:
 - The green arrow will be lit up at the indication block situated at the unlocked direction;
 - The red indicator above the STOP button at the remote control will be off, instead of this the green indicator situated above the button of the unlocked direction will be lit up.
4. Unlock the opposite direction of the rotor rotation the same way if necessary.

5. Make sure the turnstile is unlocked by turning the rotor with your hand for several turns towards the unlocked direction.

To disable the turnstile mechanical unlock follow the aforementioned instructions in reverse order; put the wing panels in home position before disabling the mechanical unlock. After the mechanical unlock is disabled, make sure the turnstile is locked in proper position.

9.5 Troubleshooting

Possible faults to be corrected by the customers themselves are listed in Table 14.

For faults not listed in Table 14 we advise to consult with PERCo Technical Support Department.

Table 14. Troubleshooting and remedy

Fault	Most probable cause	Remedy
Power supplies are on, but the turnstile does not function, the RC-panel lights and the LED indicators are off.	Faulty connection or breakdown in the turnstile power supply cable (13).	Check connection the power supply cable (13) to the DIN-rail. Replace the cable if broken.
The turnstile won't open in the set direction, the RC-panel lights and the LED indicators are either off, or on but do not change their status.	Faulty connection or breakdown in the control cable.	Check connection of the control cable to the DIN-rail. Replace the cable if broken.
No "PASS A" and "PASS B" signals to the ACS-controller when the turnstile is open (the passage is not registered by the ACS).	Faulty connection, breakdown or short circuit in the control cable.	Check the "PASS A", "PASS B", "Common" connection circuits. Default, where necessary, faulty connection, breakdown or short circuit.

10 MAINTENANCE

Observe safety measures given in Sect. 7.1 when undertaking maintenance works. We advise to undertake maintenance works by at least two persons qualified in assembly and electric work, after thorough study of this Manual.

Regular maintenance works are necessary for proper performance and serviceability of the turnstile. Maintenance works for the turnstile should be undertaken twice a year or straight after a fault correction.



Note:

Adjustment of the principal units (the operating mechanism and the control unit) is not a part of the maintenance works as these units are factory-adjusted and do not require any further adjusting.

Undertake the maintenance work in the following sequence:

1. Switch off and disconnect from the mains power supply units of the turnstile and walkway downlights.
2. Take off the cover (10) from the top channel (9) (see Sect. 6).

3. Check and tighten if necessary screw joints of the turnstile.
4. Clean the inside of the top channel from possible contaminants.
5. Assure the cables are secured safely on connector blocks and clips.
6. Lubricate with machine oil type I-20 the parts of the operating mechanism in accordance with Fig. 26 (it is allowed to use aerosol silicone lubricants for low temperatures).
7. Lubricate keyholes of the mechanical release locks. Make sure the mechanical release locks work smoothly and provide reliable unlocking (free rotation) of the rotor in both directions (see Sect. 9.4).
8. Check the operation of the damper and adjust the damper if necessary (for the **RTD-20.2** model only; see Sect. 8.6).
9. Install the cover on the top channel (see Sect. 6).
10. For the maintenance of the bottom rotation unit (3) for each turnstile OD dismantle the rotor:
 - a. Carry out the dismantling of the rotor (the operation should be performed by two persons!):
 - Remove the half-couplings (see Fig. 18), undo two M8 bolts of the union joint (4). **Caution!** Keep the rotor and the half-couplings from falling.
 - Lift gently and remove the rotor (1) from the bottom rotation unit, keep a moderate slop and take the rotor out of the turnstile, lay it down on a steady surface.
 - b. Remove the slip washers and fluoroplastic liners (see Fig. 14) from the bottom rotation unit (3).
 - c. Make sure the anchor bolt of the bottom rotation unit is tightened properly, tighten the bolt if necessary.
 - d. Clean the washer and friction surfaces of the bottom rotation unit. Examine the washer and friction surfaces and make sure there are no chips, cracks or tearing. It is allowed to use a molybdenum grease.
 - e. Check for gaps all joints of the rotor sections in sequence. Line up the sections, take out the gaps and tighten the bolts of M8 fastenings if necessary (see Fig. 19).
 - f. Install the rotor following the correct installation order (see Sect. 8.4, point 17). The operation should be performed by two persons!
11. Make sure the flanges of the turnstile are tightly anchored to the mounting surface. Tighten the bolts if necessary.
12. Check the operation of the turnstile in accordance with Sect. 8.8 and the operation of the optional equipment (if applicable).

Upon completion of the maintenance works and testing the turnstile is ready for further use.

We advise to consult with PERCo Technical Support Department in case some parts are found faulty during the maintenance works.

Repair of painted surfaces

If there is a necessity to repair damaged painted surfaces of the turnstile use powder paint from the standard delivery set of the turnstile (see Sect. 4.1) and follow these instructions:

1. Degrease and dry the damaged surface.
2. Dilute powder paint in necessary amount of acetone to get a creamy paste. Consider that the paint starts polymerization within 7-10 min.

3. Apply the paint on the damaged surface with brush or sponge.
4. Dry the repaired surface until the paint is solid. Approximate drying time at the standard room temperature is 3-4 hours.




Figure 26. Operative device installed in the top channel, with the indication of lubrication points; the view from above

11 TRANSPORTATION AND STORAGE

The turnstile in the original package should be transported in closed freight containers or closed type cargo transport units (railway carriages, containers, closed cars, ship's holds etc.).

During storage and transportation, the boxes can be stacked no more than 2 layers high. Box dimensions and weight are given in Table 4.

The turnstile should be stored indoors at ambient temperatures between -40°C to $+50^{\circ}\text{C}$ and relative air humidity up to 98% at $+25^{\circ}\text{C}$. The storage facilities should be free from acid, alkalis and corrosive gases.

If prior to installation the turnstile was transported or stored at below-zero temperatures or high air humidity, it should be kept in package for no less than 24 hours under operation conditions given in Sect. 2.

APPENDIX 1. Algorithm of control signals generation in pulse control mode

The command is an active edge of the signal (the transition of the signal from high level to low level) at the appropriate contact relative to the levels of the signals at the other contacts.



Note. For the RC-panel:

Active front – the moment of pushing a respective button on the RC-panel;
 Low level – the respective button on the RC-panel is pushed;
 High level – the respective button on the RC-panel is not pushed.

By feeding a low-level signal relative to the *GND* contact to the DIN-rail contacts *Unlock A*, *Stop* and *Unlock B*, the following commands can be generated.

"*Always locked*" (the turnstile is closed for entry and exit) – the active front at the *Stop* and a high-level signal at the *Unlock A* and *Unlock B* contacts. Both directions are closed by this command.

"*Single passage in direction A*" (the turnstile is open for a single passage of one person in direction A) – the active front at the *Unlock A* contact and a high-level signal at the *Stop* and *Unlock B* contacts. This command opens direction A either for 5 seconds, or until completion of the passage, or until the "Always locked" command is given, whereas status of direction B will not change. The command is ignored if it is received at the moment when direction A is in the "Always free" mode.

"*Single passage in direction B*" (the turnstile is open for a single passage of one person in direction B) – the active front at the *Unlock B* contact and a high-level signal at the *Stop* and *Unlock A* contacts. This command opens direction B either for 5 seconds, or until completion of the passage, or until the "Always locked" command is given, whereas status of direction A will not change. The command is ignored if it is received at the moment when direction B is in the "Always free" mode.

"*Bidirectional single passage*" (the turnstile is open for a single passage of one person in each direction) – the active front at the *Unlock A* contact opens direction A with a high-level signal at the *Stop* contact, and the active front at the *Unlock B* contact opens direction B with a high-level signal at the *Stop* contact, sequence order of the fronts being of no difference. This command opens both directions, each for either 5 seconds, or until completion of the respective passage, or until the "Always locked" command is received. The command is ignored for either direction if it is received when this direction is in the "Always free" mode.

"*Free passage in direction A*" (the turnstile is open for multiple passage in direction A) – an active front at the *Unlock A* contact, a low-level signal at the *Stop* and a high-level signal at the *Unlock B* contact, or the active front at the *Stop* contact, a low-level signal at the *Unlock A* contact and a high-level signal at the *Unlock B* contact. This command opens direction A until the "Always locked" command is received, whereas status of direction B will not change.



Note:

When the passage direction B is open and the command "*Free passage in direction A*" is issued at once the time slot between the edges of the signals *Stop* and *Unlock A* should not exceed 30 ms (which corresponds to simultaneous press of the buttons). Otherwise the command may be adopted as "*Always locked*" and the direction B may be blocked. This note is also relevant for the situation when the command "*Free passage in direction B*" is issued (taking into account the change of direction indexes).

"Free passage in direction B" (the turnstile is open for multiple passage in direction B) – the active front at the *Unlock B* contact, a low-level signal at the *Stop* contact and high-level contact at the *Unlock A* contact, or the active front at the contact *Stop*, a low-level signal at the *Unlock B* contact and a high-level signal at the *Unlock A*. This command opens direction B until the "Always locked" command is received, whereas status of direction A will not change.

"Always free" (the turnstile is open for multiple passages in both directions) – the active front at the *Unlock A* contact with a low-level signal at the *Stop* contact and the active front at the *Unlock B* contact with a low-level signal at the *Stop* contact, or the active front at the *Stop* contact with a low-level signal at the *Unlock A* and *Unlock B* contacts, sequence order of the fronts being of no difference. This command opens both directions until the "Always locked" command is received.

APPENDIX 2. Algorithm of control signals generation in potential control mode



Note. For ACS-controller outputs:

- Low level – output relay contacts are closed, or the output transistor is open;
- High level – output relay contacts are open, or the output transistor is closed.

"Both directions closed" (the turnstile is locked for entry and exit) – a high-level signal at the *Unlock A*, *Unlock B* contacts or a low-level signal at the *Stop* contact. This command closes both directions.

"Direction A open" (the turnstile is open for passage in direction A) – a low-level signal at the *Unlock A* contact and a high-level signal at the *Stop*, *Unlock B* contacts. This command opens direction A until a low-level signal is removed from the *Unlock A* contact, or the "Both directions closed" command is received, whereas status of direction B will not change.

"Direction B open" (the turnstile is open for passage in direction B) – a low-level signal at the *Unlock B* contact and a high-level at the *Stop*, *Unlock A* contacts. This command opens direction B until a low-level signal is removed from the *Unlock B* contact, or the "Both directions closed" command is received, whereas status of direction A will not change.

"Both directions open" (the turnstile is open in for passage both directions) – a low-level signal at the *Unlock A* and *Unlock B* contacts and a high-level signal at the *Stop* signal. This command opens both directions until a low-level signal is removed from either *Unlock A* or *Unlock B* contact, or the "Both directions closed" command is received.

APPENDIX 3. The markup schemes for joint installation of checkpoint components and RTD-20




Figure 27. Example of mutual position of the turnstile with swing gate WHD-16 and railing system MB-16




Figure 28. Installation marking diagram of the turnstile with the swing gate WHD-16




Figure 29. Installation marking diagram of the turnstile with the railing system MB-16




Figure 30. Installation marking diagram of the turnstile RTD-20 together with the special cable duct for the cable grooming from below.

PERCo

Polytechnicheskaya str., 4, block 2
194021, Saint Petersburg
Russia

Tel: +7 812 247 04 64

**E-mail: export@perco.com
support@perco.com**

www.perco.com



www.perco.com